


#### **Profiles:**



**TRACE™** Horizontal

TRACE™ is an indoor/outdoor low voltage lighting system used primarily for direct or indirect lighting designs.

### Please verify the contents of the packages!

## Please read instructions entirely before starting installation

# Be sure power is turned off before installing the system Call Tivoli, LLC tech support with questions

**Caution:** TRACE<sup>™</sup> is designed to work with listed Class 2 24V DC transformers only. Use of any other power source will cause damage, shorten the life of the fixture and will void the warranty.

**Consult** any and all applicable local and national codes for installation.

**Do not** conceal or extend exposed conductors through a building wall as per local electrical code.

**Warning:** With any luminaire for any application, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injuries. This lighting system should be installed by a certified professional.

### **WARNINGS**








**TRACE™ MAY BE EASILY DAMAGED!** The reliability of the product can only be ensured if these warnings and cautions are complied with faithfully. Keep these instructions for future maintenance work.

#### **WARNING!** Risk of product damage.

Longer runs of Trace<sup>™</sup> lighting strands must be installed by at least two people.


**IMPORTANT!** The Trace<sup>™</sup> luminaire must not be allowed to bend or hang down. That way, the bending limit will not be inadvertently exceeded, resulting in product damage.



Keep Trace $^{™}$  from twisting or bending in the wrong direction. Two person installation.

### Warning! Risk of product damage.

Trace™ Horizontal must not be bent at less than 2.0″ diameter or damage will result. Do not allow Trace™ to twist or bend in the wrong direction.



Bending Diameter 2.0"

7101006




### Overview: Read Before Installing Luminaire

#### **Installation Notes:**

**Step 1:** Measure run area where  $Trace^{T}$  is to be installed. Locate power feed end at highest point of the run to minimize exposure to water run off.

**Step 2:** A Mounting Channel is recommended for outdoor applications. Lay channel along desired area and attach with screws (by others) every 18 to 24 inches. If the design requires creating bends and arcs, it is recommended that the Horizontal Notched Channel be used. Mounting Clips are for use on indoor applications only.

**Note:** Minimum bending diameter for the notched channel is 11". Trace™ Horizontal must not be bent less than 2" diameter or damage will result.



**Step 3:** Trace™ must be installed with two people. One to press the luminaire into the channel and the other to hold the spool and unroll it while keeping the Trace™ flex body straight.

Warning: Risk of Product damage.


Do not stretch, pull, or yank. Doing so can damage the Trace  $^{\!\top\!\!}$  internal connections and void the warranty.

**Step 4:** The Power Feed Connectors and End cap will overhang outside the ends of the Channel. Measure length of Trace Run and cut 2.25" off the length of the mounting channel. Insert Trace™ into mounted channel starting from power connector end. Trace™ should be pressed into the channel carefully and gradually, without excessive bending or damage will result.

**Note:** We recommend using a dry spray lubricant, such as 3M Spray Lubricant or WD-40 Specialist for all Trace™ installations to insure the luminaire fits into the channel without damage. Additionally, Silicone Sealant (**FLXD-SIL-GE-10**) must be applied to the inside bottom surface.

**Step 5:** Secure power connection to building with use of C-clamp (by others) or mount connection inside J-Box.

Connect to 24V DC power supply according to supplied wiring diagrams.





### **Trace Mounting Options**

### **Trace™ Horizontal with Mounting Clips**

Warning: Risk of Product Damage.

Only bend the Trace  $^{\mathrm{m}}$  Horizontal so the lens bends side to side. See diagram below.

**Note:** Minimum bending diameter for Trace<sup>TM</sup> Horizontal is 2'' in the horizontal direction only.

**Step 1:** Determine where the Mounting Clips will need to be installed to achieve the desired shape.

**Step 2:** Position the Mounting Clips and attach with screws (Included).

**Step 3:** Lay a bead of Silicone Adhesive (**LFXD-SIL-GE-10**) to the inside bottom surfaces of the Mounting Clips, as shown.

**Step 4:** Spray Dry Lubricant on a rag and wipe the inside upper surfaces of the mounting clips, as shown, to allow the Trace™ fixture to slide more easily into the mounting clip. 3M Spray Lubricant or WD-40 Specialist is recommended.

Warning! Risk of Product Damage.

Regular WD40 490002 will stress craze, crack or swell the Trace™ Silicone covering. Do not use!

**Step 5:** Trace<sup>™</sup> must be installed with two people. One to press the luminaire into the channel and the other to hold the spool and unroll it while keeping the Trace<sup>™</sup> flex body straight.

**Step 6:** Press Trace<sup>™</sup> into the Mounting Clip carefully and gradually, without excessive bending or damage will result.

### WARNING! Risk of Product Damage.


Do not hammer or pound the luminaire into the channel. Once inserted, do not pull or yank on the fixture. Trace™ will be damaged unless it is handled carefully.


Step 7: Connect to power.



**Warning!** Risk of Product Damage.

Trace™ Horizontal can only be bent in the direction that does not twist the Tape Light.







### **Trace Mounting Options (Continued)**

### Install Trace™ Horizontal in Notched Mounting Channel

Warning: Risk of Product Damage.

Only bend the Trace™ Horizontal so the lens bends side to side so as not to twist the Tape Light. See diagram.

**Note:** Minimum bending diameter for the notched channel is 11''. However, the minimum bending diameter for Trace<sup>TM</sup> Horizontal is 2'' in the horizontal direction only.

**Step 1:** Determine Channel mounting Location.

**Step 2:** Drill a hole 3" from each end of the Channel and 18"-24" along length of Channel.

**Step 3:** Position the Notched Channel and attach with screws (Included).

**Step 4:** Lay a bead of Silicone Adhesive (**LFXD-SIL-GE-10**) to the inside bottom surface of the notched mounting channel, as shown.

**Step 5:** Spray dry lubricant on a rag and wipe along the inside upper surfaces of the extrusion. We recommend using a dry spray lubricant, such as 3M Spray Lubricant or WD-40 Specialist for all Trace installations to insure the luminaire fits into the channel without damage.

**Step 6:** Start by orienting the Trace  $^{\text{\tiny{TM}}}$  with the Lens facing away from the Channel, as shown.

**Step 7:** Trace™ must be installed with two people. One to press the luminaire into the channel and the other to hold the spool and unroll it while keeping the Trace™ flex body straight.

**Step 8:** Insert the Trace<sup>™</sup> body into the Channel one flex section at a time. Start at one end and and press it down carefully and gradually, working along the Channel, inserting the Trace<sup>™</sup> body into each section until the entire Trace<sup>™</sup> fixture is securely mounted in the channel.

#### **WARNING!** Risk of Product Damage.


Do not hammer or pound the luminaire into the channel. Once inserted, do not pull or yank on the fixture. Trace $^{\text{m}}$  will be damaged unless it is handled carefully.


Step 9: Connect to power.

#### **Bending Limitations**

Warning! Risk of Product Damage.

 $Trace^{\mathbf{m}}$  Horizontal can only be bent in the direction that does not twist the Tape Light.









### Trace Mounting Options (Continued)

### Straight Channel for Trace™ Horizontal Installation

**Step 1:** Prepare Straight Mounting Channel for installation cutting it to the correct length, keeping in mind that the End Caps will not fit inside the Channel, and by drilling screw holes 3" from each end and additional holes approximately every 18" along the channel.

**Step 2:** Place Straight Channel on the mounting surface and mark the hole locations.

**Step 3:** Remove the Channel and drill pilot holes at all hole locations.

**Step 4:** Place the Channel into position and secure with screws (not included).

**Note:** Screws should be appropriate for the mounting location. (ie: wood screws for wood, etc.)'

**Step 5:** Lay a bead of Silicone Adhesive (**LFXD-SIL-GE-10**) to the inside bottom surface of the straight channel, as shown.

**Step 6:** Spray dry lubricant on a rag and wipe along the inside upper surfaces of the extrusion. We recommend using a dry spray lubricant, such as 3M Spray Lubricant or WD-40 Specialist for all Trace<sup>TM</sup> installations to insure the luminaire fits into the channel without damage.

**Step 7:** Trace™ must be installed with two people. One to press the luminaire into the channel and the other to hold the spool and unroll it while keeping the Trace™ flex body straight.

**Step 8:** Start by orienting the Trace<sup>™</sup> with the Lens facing away from the Channel, as shown.

**Step 9: IMPORTANT!** Insert the Trace<sup>™</sup> body into the Channel. Start at one end and press it down carefully and gradually, working along the Channel, inserting the Trace<sup>™</sup> body along the channel until the entire Trace<sup>™</sup> fixture is securely mounted in the channel.

### WARNING! Risk of Product Damage.

Do not hammer or pound the luminaire into the channel. Once inserted, do not pull or yank on the fixture. Trace $^{\text{m}}$  will be damaged unless it is handled carefully.


Step 10: Connect to power.


#### **Bending Limitations**


Warning! Risk of Product Damage.

Trace<sup>™</sup> Horizontal can only be bent in the direction that does not twist the Tape Light.











7101006



## Trace<sup>™</sup> Mounting Options (Continued)



**Note:** Trace  $^{\text{\tiny{M}}}$  Mounting Channel can be mounted on horizontal or vertical surfaces.



LUMINAIRE	MAX CONTINUOUS RUN LENGTH		
Trace	Low Output	Standard	High
	58′	29′	19′



### Power Supply with 0-10V Sample Wiring Diagram

There are many possible options for dimming Trace™. See the specification Sheet for more information. The following wiring diagram is for reference only. Please refer to the Installation Instruction for the Power Supply you choose for detailed wiring instructions.

